

Deep Clean Regime

(weekly/fortnightly)
dependant on usage



1.

Remove all foreign debris from the urinal bowl (including paper, gum, tissue and rubbish)

2.

Remove the cartridge (ensuring the valve clamp and valve are clear of debris and in position)

3.

Clean the urinal waste outlet with a pan brush or scourer (to remove tough stains/debris)

4.

Flush a small amount of diluted cleaner (one 15ml measure/half sachet of cleaner into a bucket of water) through each urinal

5.

Please ensure the cartridge is replaced correctly (ensuring it is fitted to the "lugs" on the waste outlet)

